

Accessing the Menu

Press the center "flame" button on the console to bring up the on-screen menu or press the same flame button of your remote.

Pinning Apps

From the applications folder, press and drag your most frequently used apps onto the menu to pin them for easy access.

Creating Shortcuts

Open Chromium from the applications folder, navigate to the website you want to add, select the 3-dot menu in the top right corner and choose "Add to Home Screen." You can rename the shortcut before you save it.

Turning Off Touch Sounds

From the menu, go to the applications folder and then tap Settings > Sound > toggle off Touch Sounds.

Adjusting Date & Time

From the menu, go to the applications folder and then tap Settings > Scroll down and tap System > Date & Time

Changing Wallpaper

From the menu, go to the applications folder and then tap Settings > Display > Advanced > Wallpapers. Select "My Photos" to choose your own image. Press the 3-line menu in the top left corner to navigate between storage spaces.

Note: you may also change your wallpaper through your Promethean account at one.prometheanworld.com.

Opening Files

From the menu, go to the applications folder > Files > Select the 3-line menu in the top left corner to navigate between storage spaces.

Locking Screen

Press the flame button, tap your profile name in the bottom left corner > Lock Screen.

Note: This will NOT sign you out of your profile.